ASTER Science QA: Lessons Learned

QAWG Boulder, CO 27 Mar 01

Craig Leff
cleff@crow.jpl.nasa.gov
Gary Geller
ggeller@crow.jpl.nasa.gov
Duane Kiefer
kiefer@crow.jpl.nasa.gov



Agenda

- Some Specific Features
- Overview of QA Flow
- Data Product Status
- Methods and Procedures
- Lessons Learned



Some Specific Features of ASTER Science QA


- Alerts: QA-relevant summary statistics are calculated within the Level 2 PGEs for each granule (e.g., the percent of bad pixels in a scene.)
 - When any of these summary statistics is outside their assigned ranges, an "alert" is raised.
 - Ranges are stored in a look-up table and can be easily changed to reflect improved knowledge.
 - Alert information is written to an archived Alert Log and to the data product header for end-user's reference.
- Data Planes: Each ASTER data product will have one or more data planes containing pixel-level QA information.
 - These planes are created in addition to the science data planes and map to the science data on a pixel-by-pixel basis.



Some Specific Features of ASTER Science QA

- First QA plane: Common structure for all data products.
 - » Each pixel will be marked as Good, Bad or Suspect, and its cloudiness noted.
- Second QA data plane: optional.
 - » Structure varies according to data product.
- Both data planes: Simple graphical display of bad data and other QA information
 - » Easy to see where scenes were most affected
- Data Product Sampling: Determined by complexity of algorithm and dependence on external data sources.
 - Number of products examined based on daily number of granules produced, percent to be examined and resources available to do the QA.





Data Product Status

- Currently publicly-released are:
 - Decorrelation Stretch
 - Brightness Temperature Separation
 - Atmospheric Correction-VNIR/SWIR (Surface Reflectance and Surface Radiance)
 - DEM (N.B.: QA done at DAAC with involvement of algorithm developer.)
- Public release expected soon:
 - Atmospheric Correction-TIR (Surface Radiance-Thermal)
 - Surface Kinetic Temperature and Surface Emissivity
- Decorrelation Stretch and Brightness Temperature Separation are based on well-proven algorithms and their QA needs are low.

Methods and Procedures

- ASTER uses cw_look, an IDL-based package developed by Duane Kiefer of the ASTER PGS
- cw_look can:
 - Open and display HDF, HDF -EOS and other file types, including display of the embedded metadata files (e.g., coremetadata.0, productmetadata.0, etc.)
 - Do simple image processing tasks, such as:
 - » contrast enhancements
 - » zooms
 - » pans
 - » 3-D display of brightness values
 - Save images as GIF, JPEG or TIF



Methods and Procedures

- ASTER-US produces only Level 2 data products and we QA only those products.
- Subscribed to all Ingest data notifications and store the resulting email messages for sorting and searching
 - Based on the data in the notifications, sample data products for QA based on geographic location, date of collection or date of processing.
- Use EDG to order data products for ftp pull.
 - Use lat/lon and/or time constraints, as Granule ID searching of ASTER data products has not been available for much of the mission to date.
- Examine data products according to the QA guidelines in the QA Plan.
 - Guidelines were agreed upon with the algorithm developers



Methods and Procedures

- Data production delays have delayed Science QA operations and true Science QA is just getting started.
- Most ASTER QA thus far has been done by the algorithm developers (e.g., metadata errors, SWIR misregistration.)
- Resources dedicated to formal Science QA have been limited.



Lessons Learned

- Algorithm developers need to acclimate to the availability of alerts and QA data planes
 - Even though they were developed with the science team and approved by them, these are new concepts
 - Science team still learning how to use them
 - Salesmanship needed on part of QA developers
- Concept of alerts does appear to be useful
- Data plane concept still being evaluated
- Be flexible as to schedule and procedures, which will change no matter how well you plan or how thorough your QA Plan document is



Lessons Learned

- Devote sufficient resources for the level of QA you have committed to.
- Important to have QA personnel be closely allied with PGS.
 - Knowledge of PGS and DAAC procedures was often as important (or more important) than the science knowledge needed for QA per se.
- Maintaining a good working relationship with the DAAC was key to resolving processing and QA issues.

